

## Racine Adapters Cleaning and Sterilization Guidelines (SunMed)

**Disinfection & Sterilization Procedures are Steam for 30 minutes at 120°C and Cidex can be used: follow manufacturer guidelines.**